Gleiphir

USER GUIDE

Real Wireless Bluetooth Earphones

● 包装内容



耳机*1副 充电仓*1个 收纳袋*1 Type-c 充电线*1 说明书*1

● 产品概述



● 与手机配对

首次使用，从充电盒取出耳机，再把耳机放回充电盒中激活，耳机白灯亮。再次把耳机从充电盒取出后，双耳将自动开机自动配对。当一边的指示灯为白灯快闪，另一边为白灯慢闪时，左右耳机配对成功。在手机上搜索"Gleiphir HF1"便可与之连接。

注意：如果耳机没有正常充电激活，将耳机放回充电盒，用Type-c充电线给充电盒充电，耳机白灯亮。

● 恢复出厂设置

① 把耳机放回充电盒，使之为充电状态，此时白灯长亮；
② 从充电盒单独取出左耳机或右耳机，当白灯闪烁时，长按功能键6s，直到白灯熄灭，然后放回充电盒；
③ 从充电盒取出另一只耳机，重复以上操作；
④ 最后同时取出两只耳机，白灯闪烁后，直到一边耳机白灯快闪，另一边耳机白灯慢闪，左右耳机配对成功。在手机上搜索"Gleiphir HF1"，点击便与手机连接成功。

● 充电

给充电盒充电
请使用Type-c充电线充电。充电时，充电盒白灯闪烁；充满电后，充电盒白灯长亮；低电量时，充电盒白灯闪烁。

给耳机充电
把耳机放回充电盒，当耳机正在充电时，耳机白灯长亮；充满电后，耳机白灯熄灭。

● 触摸键功能

通话
来电拒接：长按左/右耳机2s
来电接听：双击左/右耳机

音乐
播放/暂停：双击右耳机
上一首：长按左耳机2s
下一首：长按右耳机2s

语音助手
三击左/右耳机



● 产品参数

型号	Gleiphir HF1	电池类型	锂电池
传输范围	10m（无障碍）	蓝牙协议	HFP/HSP/A2DP/AVRCP
蓝牙版本	5.1	耳机电池容量	3.7V 30mAh
充电时间	约2小时	充电仓容量	3.7V/600mAh
音乐播放时长	约5小时		

*以上参数为实验室测试数据

● 非保修条例

感谢您选择本公司的产品，为了保障您的权益，请您购机后仔细阅读以下内容（以下情况不属于免费维修范围）：
1. 未按照使用说明书使用、维护、保管导致的产品故障或损坏；
2. 擅自涂改、撕毁产品包装及条码；
3. 已经超出保修期限；
4. 意外因素或个人行为导致产品损坏，如输入不合格电压、高温、机械破坏、产品严重氧化或生锈等；
5. 因为不可抗力如地震、水灾、火灾、雷击等导致的故障或损坏。

● 提示

1. 在使用耳机之前，请仔细阅读使用说明书并妥善保管；
2. 在第一次使用耳机之前，耳机必须要充满电；
3. 如果耳机闲置超过30天，请定期充电；
4. 请使用合格制造商生产的充电器；
5. 如果手机无法搜索到蓝牙耳机，请检查耳机是否在配对状态；如果长时间未连接，耳机将退出配对模式。如果手机发生程序错误，请重启；如耳机出现程序错误，请重启或参照恢复出厂设置步骤操作。

● 警告

1. 请勿长时间在高音量状态下使用，以防损害听力；
2. 不得以任何理由拆卸或改装耳机，以免造成任何损坏或危险；
3. 不要将耳机存放在极端温度下；
4. 避免将指示灯靠近儿童或动物的眼睛；
5. 避免在雷雨期间使用耳机，以防耳机功能混乱和增加触电风险；
6. 请勿使用刺激性化学品或强力清洁剂来清洗耳机；
7. 保持耳机和充电盒干燥。

本设备经测试证明符合FCC规则第15部分中关于B类数字设备的限制。这些限制旨在为住宅安装中的有害干扰提供合理的保护。本设备会产生使用并辐射射频能量，如果未按照说明进行安装和使用，可能会对无线电通信造成有害干扰。但是，不能保证在特定安装中不会发生干扰。如果此设备确实对无线电或电视接收造成有害干扰（可以通过打开和关闭设备来确定），则鼓励用户尝试通过以下一种或多种措施来消除干扰：
1. 重新调整或摆放接收天线；
2. 增加设备和接收器之间的距离；
3. 将设备连接到与接收器不同电路的插座；
4. 向经销商或有经验的无线电/电视技术人员咨询以获得帮助。

此设备符合FCC规则的第15部分。操作必须符合以下两个条件：
1. 此设备不会造成有害干扰；
2. 此设备必须接受收到的任何干扰，包括可能导致意外操作的干扰。

未经负责合规方明确批准的更改或修改可能会使用户丧失操作设备的权限。

产品保修卡

保修说明：自购买日起12个月内因产品质量原因免费维修

产品名称：	产品型号：
购买日期：	客户名称：
联系方式：	

产品维修记录

日期	不良现象	解决方案

● Unpack The Box



Earphones*1 Pair Charging Case*1 Carrying Bag*1 Type-c cable*1 User Guide*1

● Product Overview



● Pair With Your Phone

When used for the first time, take out both earphones from the charging case, then put them back into the charging case to activate. At this time, the light of the earphones turns white. When the earphone is taken out from the charging case again, both earphones will auto power on and pair with each other. When the indicator light on one side flashes fast for the white light and the light on the other side flashes slowly for the white light, the left and right earphones are matched successfully. Search "Gleiphir HF1" on mobile phone and you can connect with it.

Notes: If the earphone is not activated by normal charging, put the earphones back into the charging case and charge the case with Type-c cable. The white light of the earphone will be on.

● Restore Factory Settings

1. Put the earphones back in the charging case and make them in the charging state. At this time, the white light will be on long.
2. Take out the left earphone or the right earphone separately from the charging case. When the white light is flashing, long press the function button 6s until the white light is off, and then put it back into the charging case.
3. Take out the other earphone from the charging case and repeat the above operation.
4. Finally, take out both earphones at the same time and the white light flashes. When the white light of one earphone flashes quickly and the white light of the other earphone flashes slowly, the left and right earphones are matched successfully. Search "Gleiphir HF1" on your mobile phone and click it to connect with your mobile phone.

● About Charging

Charge the charging case
Please charge the case via Type-c cable. The white light on the charging case flashes as it charges. When the charging case being fully charged, the white light of the charging case will be on long. When the battery is low, the charging case's white light flashes.

Charge the earphones
Put the earphones into the charging case. When the earphone is charging, the white light of the earphone will go on long. When the earphone is fully charged, its white light goes out.

● Touch Key Functions

Phone
Reject: Long press left/right earphone for 2s.
Answer/Hang Up: Double-click the left/right earphone to answer the incoming call and double-click left/right earphone again to end it.

Music
Play/Pause: Double-click the right earphone.
Next: Press the right earphone for 2s
Previous: Press the left earphone for 2s.

Voice Assistant
Touch left/right earphone three times.

● Product Parameters

Model	Gleiphir HF1	Battery Type	Li-ion
Operation Range	10m(without obstacle)	Bluetooth Protocol	HFP/HSP/A2DP/AVRCP
Bluetooth Version	5.1	Battery Capacity (earphones)	3.7V/30mAh
Charging Time	approx 2hr		
Music Time	approx 5hr	Battery Capacity (charging case)	3.7V/600mAh

*The specifications are acquired from laboratory tested data.

● Non-warranty Regulations

Thank you for choosing our products. In order to protect your rights and interests, please read the following carefully after purchasing the machine:
(The following conditions are not covered by free maintenance.)
1. Product failure or damage caused by failure to use, maintain or storage in accordance with the operating instructions.
2. Alter or tear the product package and bar code without authorization.
3. The warranty period has been exceeded.
4. Product damage caused by accidental factors or personal behavior, such as unqualified input voltage, high temperature, mechanical damage, serious oxidation or rust of product, etc.
5. Failure or damage caused by force majeure such as earthquake, flood, fire, lightning strike, etc.

● Tips

1. Please read the manual carefully before using the earphones.
2. The earphones must be fully charged prior to the first use
3. If the earphone is left unused for over 30 days, please charge it periodically.
4. Please use chargers made by qualified manufacturer.
5. If the Bluetooth earphones cannot be found by your phone, please check whether it is in pairing mode. The earphones will exit pairing mode if left unconnected for a long while. Please reboot it when a program error of your phone occurs. Please reboot or reset it when a program error of the earphones occurs.

● Warning

1. Do not use it at high volume for a long time, so as not to damage your hearing.
2. Never disassemble or modify your earphones for any reason to avoid any damage and danger.
3. Do not store the earphones at extreme temperature.
4. Keep the indicator light away from the eyes of children or animals.
5. Avoid using earphones during thunderstorms to avoid confusion function of earphones and increased risk of electric shock.
6. Do not use irritant chemicals or strong detergents to clean the earphones.
7. Keep the earphones and charging case dry.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
1. Reorient or relocate the receiving antenna.
2. Increase the separation between the equipment and receiver.
3. Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
4. Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:
1. This device may not cause harmful interference.
2. this device must accept any interference received, including interference that may cause undesired operation.
Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Radiation Exposure Statement
The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

Product warranty card

Warranty Description: Within 12 months from the date of purchase, if a performance fault that is not caused by human damage occurs on the product, you could enjoy the free maintenance services.

Name of product:	Model type:
Date purchased	Customer name:
Contact information	

Product maintenance record

Date	Undesirable phenomenon	Solution