

11 cm

8 cm

40 cm

Hatch




Sleep Headband

FOR RESTORE



User Guide

Hatch Sleep Headband is compatible with your Hatch Restore smart sleep assistant.

To connect headband to Restore:

-  Use included Micro-USB cord to charge headband, then power on
-  Visit settings in the Hatch Sleep app
-  Select "Pair Headphones"
Once on, headband automatically connects to the last connected device available.


Headband Controls

Button	Action
Power On/Off 	Press + hold for 3 seconds
Volume Up/Down 	Short press

Note: Only 1 Bluetooth connection per Restore assistant is permitted at one time. To connect Restore device to different headphone, use phone Bluetooth settings to unpair / forget device.

Wash Instructions




- Remove control panel by pushing out of pocket then through opening at back headband.
- Similarly, remove speaker discs located on each side.
- Hand or machine wash in cold water. Lay flat to dry.



Need help? Hatch support is a dream.

Avez-vous besoin d'aide ?
Le soutien à Hatch est un rêve.

Contact us at support@hatch.co.
Contactez-nous à support@hatch.co.

Follow [@hatchforsleep](https://twitter.com/hatchforsleep) and see what dreams are made of.
Suivez [@hatchforsleep](https://twitter.com/hatchforsleep) et voyez de quoi sont faits les rêves.

Front Panel

Hatch




Le Hatch Sleep Headband

FOR RESTORE



User Guide

Le Hatch Sleep Headband (Bandeau serre-tête Hatch Sleep) est compatible avec votre assistant de sommeil intelligent Hatch Restore.

Pour connecter le bandeau serre-tête à Restore:

-  Utilisez le cordon Micro-USB inclus pour charger le bandeau serre-tête, et puis allumez-le.
-  Visitez les réglages dans l'appli Hatch Sleep
-  Sélectionnez "Pair Headphones" (Jumeler les Écouteurs)
Une fois allumé, le bandeau serre-tête se connecte automatiquement au dernier dispositif relié disponible.


Commandes du Bandeau Serre-Tete

Button	Action
Allumer/Éteindre 	Appuyer et maintenir enfoncé pendant 3 secondes
Volume fort / Volume faible 	Appuyer brièvement

Note: Une seule connexion Bluetooth par assistant Restore est autorisée à la fois. Pour connecter le dispositif Restore à un écouteur différent, utilisez les réglages Bluetooth du téléphone pour déjumeler / oublier l'appareil.

Instructions de lavage

- Retirer le panneau de commande en le poussant hors de la poche, et puis à travers l'ouverture au dos du bandeau serre-tête.
- De même, retirez les disques des haut-parleurs situés de chaque côté.
- Laver à la main ou à la machine à l'eau froide. Laissez sécher à plat.



FCC Caution: Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

IMPORTANT NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
—Reorient or relocate the receiving antenna.
—Increase the separation between the equipment and receiver.
—Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. —Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure Statement: This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. iSEDC Warning This device complies with Innovation, Science, and Economic Development Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'Innovation, Sciences et Développement économique Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes:
(1) l'appareil ne doit pas produire de brouillage, et
(2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.
The device is compliance with RF exposure guidelines, users can obtain Canadian information on RF exposure and compliance.
Le présent appareil est conforme Après examen de ce matériel aux conformités ou aux limites d'intensité de champ RF, les utilisateurs peuvent sur l'exposition aux radiofréquences et la conformité and compliance d'acquiescer les informations correspondantes.

Back Panel