




User Manual



noise-cancelling
Wireless Headphones

ELITE SERIES

What's In The Box

- Wireless Active Noise Cancelling Headphones
- USB charging cable
- 3.5 mm aux-in cable
- User Manual
- Carrying case

BT Version:	Version 5.0
Chipset:	Qualcomm QCC3005
Wireless Range:	32 feet (10 m)
Battery Capacity:	800mAh
Charging Input:	DC 5V 350mA
Charging Time:	Approximately 3 hours
Battery Life without Active Noise Cancelling:	Up to 40 hours
Battery Life with Active Noise Cancelling:	Up to 20 hours
Noise Cancellation Depth:	30±2dB
Noise Cancelling Bandwidth:	20Hz - 800Hz
Noise Cancelling Effective Frequency:	40Hz - 700Hz
Driver Size:	40mm
Impedance:	32 Ω
Rated Power:	17mW
Effective Frequency Range:	20 - 20KHz
Signal to Noise Ratio:	100dB @ 0.1mW 1kHz
Dimensions:	15.4 x 18.9 x 7.4 cm
Weight:	249.5 g

Important Safety Information



- Always consider the volume level and listening time when using any headphones. Listening to sounds that are too loud for an extended amount of time could be damaging to your hearing.
- Do not operate heavy machineries or cars while listening to or wearing your headphones. Not only is it dangerous, it is also illegal in many places.
- We do not recommend you to use the headphones while riding a bike, running or walking in heavy traffic areas.
- Keep the unit away from heat source, direct sunlight, humidity, water or any other liquid.
- Do not expose the device to extremely high or low temperatures, as it may damage the battery.
- Do not operate the unit if it has been wet or moist to prevent against electric shock and/or damage to the unit.
- Do not use the unit if it has been dropped or damaged in any way.
- There are no replaceable/serviceable parts in the headphones. Disassembling it will void your warranty.
- Clean only with a soft and dry cloth. Do not use any corrosive or abrasive cleaning agents. These could damage the surface of the device.
- Store the product and its accessories somewhere out of the reach of children, to avoid potentially fatal danger caused by inappropriate use.



Tsound02340

Features And Functions

- 1) Status LED
 - green - ANC mode
 - white - ambient sound mode
 - red - battery is charging
 - flashes red & blue - pairing mode
 - green - battery fully charged
- 2) Active Noise Cancelling mode / Ambient sound mode
- 3) Multi Function Button (MFB)
 - slide button down to power on
 - slide button up to power off
 - slide button down twice to enter manual pairing mode
- 4) 3.5mm AUX input
- 5) Type-C charging port
- 6) Volume Up (swipe up)
- 7) Volume down (swipe down)
- 8) Next Track (swipe forward)
- 9) Previous Track (swipe backward)
- 10) Play / Pause (tap twice)
 - Activate Siri / Google Assistant - tap and hold 3 seconds
 - Answer / End call - Quick tap
 - Reject Call - tap and hold
- 11) Adjustable Headband



Operations

Power ON

- Slide button down to power on
- Headphone will enter pairing mode within 5 seconds (voice prompt: bluetooth pairing on), indicated by red and blue color LED flashing alternatively
- Turn on bluetooth on mobile phone or computer
- Select "Tsound02340" to pair the device
- Voice prompt: connected if pairing successful
- LED turn blue flash every 5 seconds
- Slide button up to power off (voice prompt: power off)

Power OFF

- Slide button up to power off

Active noise canceling

Press ANC button (2) to activate noise canceling. When ANC mode is on, status LED (1) will turn green. Press ANC button (2) again to active ambient sound mode, when ambient sound mode is on, status LED (2) will turn white. Press and hold ANC button (2) will turn off both ANC and ambient sound, status LED (1) will go off.

Charging your headphones

- 1) Connect the type-c charging cable with your headphones and connect the other end to your PC, power bank or other charging device with DC 5V 500mA output.
- 2) The status LED will turn RED when charging.
- 3) Headphone will be fully charged in approximately 3 hours.
- 4) The status LED will turn GREEN when fully charged.
- 5) When the battery is low, there will be voice prompts to remind you to re-charge.

Connect to mobile device the first time

- 1) Activate the bluetooth function of the mobile device.
- 2) Turn on the unit.
- 3) When the unit is on, it will enter automatic pairing mode.
- 4) Look in the bluetooth menu of the mobile device for the pairing name "Tsound02340", select to connect the device.
- 5) The status LED flashes blue every 5 secs
Note: When headphones are powered on, it will automatically attempt to reconnect to the last device it was connected to. If it does not reconnect or if you want to connect to a new device, please repeat the above steps. You can also slide the power button down twice to enter bluetooth pairing mode manually.

Playing music

- Tap the nodnod logo (10) twice to play or pause
- To adjust volume up, use your finger to swipe up (6)
- To adjust volume down, use your finger to swipe down (7)
- To advance to next track, use your finger to swipe forward (8)
- To play previous track, use your finger to swipe backward (9)

Wearing detection function will play music automatically when wear and pause when removed Ambient Sound Mode allows you to hear ambient sound even while wearing headphones. However, note that this mode does not enable you to hear all sounds around you. Ambient sound may not be heard well depending on the surrounding environment, type of the music being played on your device, or the volume level.

Active noise-cancelling mode can reduce unwanted ambient sounds using active noise control, makes it possible to listen to audio content without raising the volume excessively. It can also help you sleep in a noisy vehicle such as an airliner. In the aviation environment, noise-cancelling headphones increase the signal-to-noise ratio significantly making hearing important information such as safety announcements easier. It can improve listening enough to completely offset the effect of a distracting concurrent activity.

If you're experiencing further problems, please contact us at:
support@ideastreamproducts.com / 1-866-459-2400.

FCC Warning

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.